


Spring Hinge G-G

Montageanleitung · Instruction Manual · Instructions d'installation · Instrucciones de instalación · Istruzioni per l'installazione · Szerelési útmutató · Monteringsanvisning · Installatie-instructies · Инструкция по монтажу


1. Remove cone tip

Unscrew the cone tip by hand.



2. Release locking screw



Loosen the lateral set screw using a 2.5 mm hexagon key.



3. Adjust spring preload



Increase the spring preload by turning the adjustment screw clockwise with a 6 mm hex key. The screw has six detent positions for incremental adjustment. Hold the adjustment screw in position with the 6 mm hex key and simultaneously secure the setting by tightening the lateral set screw with a 2.5 mm hex key (see step 2).

Note: The Hinge has no zero-position-setting. The adjustment must be limited by a mechanical end stop.



4. Reinstall cone tip

Screw the cone tip back on until fully seated (see step 1).



Bohle Worldwide

Germany

Bohle AG
42781 Haan
T +49 2129 5568-0
info@bohle.de

Austria | Hungary Slovenia

Bohle GmbH
1230 Wien
T +43 1 804 4853-0
info@bohle.at

Benelux

Bohle Benelux B.V.
3905 LX Veenendaal
T +31 318 553151
info@bohle.nl

China

Bohle Trading Co., Ltd
Tianhe District, Guangzhou
T +86-20-38105870
jiang.du@bohle.de

Croatia

Bohle d.o.o.
51000 Rijeka
T +385 051-329-566
info@bohle.hr

Estonia

Bohle Baltic
13619 Tallinn
T +372 6112-826
info@bohle.ee

France

Bohle AG · Departement Français
42781 Haan, Germany
T +49 2129 5568-222
france@bohle.de

Italy

Bohle Italia s.r.l.
20080 Vermezzo (MI)
T +39 02 94967790
info@bohle.it

Spain | Portugal

Bohle Complementos del Vidrio S.A.U.
08029 Barcelona
T +34 932 615 361
info@bohle.es

South Africa

Bohle Glass Equipment (Pty) Ltd.
2125 Gauteng
T +27 11 792-6430
info@bohle.co.za

USA | Canada

Bohle | Portals
Kansas City, MO 64106
T +1 888 838 6006
info@bohle-america.com

USA | Canada

Bohle | Portals
Charlotte, NC 28273
T +1 888 838 6006
info@bohle-america.com

United Kingdom

Bohle Ltd.
Dukinfield, Cheshire, SK16 4PP
T +44 161 3421100
info@bohle.ltd.uk

Bohle AG
Dieselstraße 10
42781 Haan

T +49 2129 5568-0

info@bohle.de
www.bohle.com